



BARRACHINA'S

TECHNICAL INFORMATION

5. CREAMS

5.1 SELF-BRIGHTENING CREAMS

5.1.1 INCREMA

CHARACTERISTICS:

Mixture of acrylic polymers, waxes and leveling and touch additives in a aqueous-alcoholic medium. It has a creamy milky yellow aspect and when applied to a shoe it gives a nice and **natural average power gloss and a dry waxy lightly sliding touch.**

APPLICATION FIELD:

It gives good results in every kind of leather, but especially on **Nappa** and those leathers with an average Nappa-like gloss. It can act like a base or filler in some cases, as it has good filling and adherence power. That's why in some special cases, it can solve problems of **blindness of grain** in Box-Calf or Kid-Skin leather. It admits watery glosses afterwards.

INSTRUCTIONS FOR USE:

After thoroughly cleaning leather from glues and other dirt, and after repairing and leveling colours if necessary, you will apply colourless or coloured INCREMA with a sponge. It is advisable to use proper sponges with great resistance, high density, very soft and small cells, able to spread product as uniformly as possible. When it is dry, after 3 to 5 minutes approximately, you will brush the shoe with a horsehair brush, and a cotton or wool brush afterwards, at 500 to 800 r.p.m. This last brush can be impregnated with our BRIGHTENING WAX. It is convenient and advisable the colourless or coloured INCREMA to be applied in good ventilation and hand protection conditions to avoid any allergic reaction or irritation.

SECURITY:

Look up the general security section.

REMARKS:

Our zone laboratories can give INCREMA any aniline colour if needed, to enhance or equalize the shoe general tone.

Barrachinas cannot control the conditions under which its products are used, therefore do not accept responsibilities concerning the results and/or consequences from its usage.